


VI0204PT(230-50)



NO.	DESCRIPTION	PART NO.	QTY
1	Cylinder head	101017	1
2	Bolt/washer cylinder head	353015	1
3	O-Ring	333011	1
4	Round-head bolt	353010	2
5	In & Outlet valve plate	115004	2
6	Outlet valve seat	114006	1
7	O-Ring	333005	1
8	Cylinder	201020	1
9	Ring press plate	218001	1
10	Piston ring plate	208003	1
11	Piston rod	316009	1
12	Bearing	315017	1
13	Crankshaft	302024	1
14	Crankcase	301020	1
15	Crankcase front cover	304019	1
16	Round-head bolt	353021	6
17	Front cover packing	215014	1
18	Out six-angle nut	371003	4
19	Motor	251913	1
20	Unloading elbow	151002	1
21	Unloading tube	228044	1
22	Unloading elbow	152101	1
23	Check Valve	409017	1
24	Pressure switch	412012-1	1
25	Tube plug	360011	3
26	Safety valve	407005	1
27	Pressure gauge	411038	2
28	Unloading tube	240056	1
29	Regulator	410008	1
30	Quick coupler	447009	1
31	Air tank	401137	1
32	Rubber handle	435020	1
33	Drain cock	406001	1
34	Tank feet	434002	4
35	Power wire	452043	1
36	Unloading elbow	151009	2
37	Tube plug	439003	2
38	Plate washer	381022	4
39	Plastic washer	384003	4
40	Round-head bolt	353024	8
41	Unloading tube	228038	1
42	Plastic washer	381021	4
43	Strain relief clip	457005	2
44	tube nut	373001	3
45	copper plug	360013	1
46	Valve cylinder rod kit(#3-#12)	VCR-0204PT	